

TAURUS PRO TW4 MIG TORCHES

Description

General guidelines to assist with the selection of a MIG torch:

- Ensure the torch length is appropriate for the required welding operation.
- Confirm the torch connection fits the welding machine.
- Ensure the correct-sized tip and liner are used for the welding wire size.
- The appropriate liner should be used for the filler-wire material type.
- Ensure that the torch amperage is sufficient for the application.
- Confirm that the duty cycle of the MIG torch selected is suitable for the application.

The Taurus TW4 MIG torch comes with the following;

- 1 x TW4 MIG torch with euro end
- 1 x TW4 coarse thread outer nozzle
- 1 x TW4 coarse thread nozzle insulator
- 1 x 1.2mm TW4 contact tip
- 1 x TW4 tip adaptor/gas diffuser
- 1 x 4m TW 4/5 yellow steel liner

TAURUS TW4 CONTACT TIPS

THREAD SIZE	HOLE DIAMETER(mm)
M6	



- 0.8 [01.14H30]
- 0.9 [01.14H35]
- 1.0 [01.14H40]
- 1.2 [01.14H45]
- 1.4 [01.14H52]
- 1.6 [01.14H116]

TAURUS TW4 NOZZLE



- 16MM [01.24CT62]

TAURUS TW4 NOZZLE INSULATOR



- [01.34CT]

TAURUS TW4 TIP ADAPTOR WITH GAS DIFFUSER



- M6 [01.54A]

TAURUS TW4 STANDARD STEEL LINER



- 4.5M [01.44.116]
- 5.4M [01.44.116.5]

TW4 MIG TORCH REPLACEMENT ACCESSORIES

CONDUCTOR TUBE



- For Taurus-Pro TW4 torch [02.64A60-PRO]
- Universal TW4 torch [02.64A60]

Taurus Pro conductor tube is not compatible with other brands. Use the universal conductor tube if it’s not a Taurus-pro torch.

TORCH HANDLE AND TRIGGER SWITCH



- Handle for Taurus-Pro torches [HANDLE-PRO]
- Switch for Taurus-Pro torches [HANDLE-PRO-SW]

Taurus Pro handle and switch are not compatible with other brands.

Product Category

1. Mig Torches
2. Mig Torches and Accessories
3. TW Torches

Date Created
07 Aug 2025